17128

OPERATION MANUAL FOR KEYBOARD
(FKB4700 SERIES)

INSTALLATION

When installing the keyboard, make sure that the keyboard is not exposed to direct sunlight. Also, avoid installing it in a dusty place.

(1) Connecting keyboard

The keyboard cable connects to the host computer with a 6 pin MINI-DIN or 5 pin DIN male connector. Fig. 1 and 2 shows the pin configuration of the cable connector.

Please make sure before connecting the keyboard that the power of the host computer is turned off.

<KEYBOARD CABLE CONNECTOR>

MINI-DIN TYPE



PIN No.	Signal
1	DATA
2	N.C.
3	GROUND (SG)
4	+5 Vdc
5	CLOCK
6	N.C.
SHELL	GROUND (FG)

Fig. 1

<KEYBOARD CABLE CONNECTOR>

DIN TYPE



PIN No.	Signal
1	CLOCK
2	DATA
3	N.C.
4	GROUND (SG)
5	+5 Vdc
SHELL	GROUND (FG)

Fig. 2

FCC Class B Notice

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communication. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio / TV technician for help.

FCC WARNING: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.